



Neo-Pure® Big Bubba® Compatible Cartridge Installation Guide

Prepare for Installation:

1. Close inlet valve to filter housing.
2. Drain housing.
3. Relieve pressure on housing.
4. Remove lid closure.
5. For best results, lubricate the new filter's lower O-rings with silicone based lubricant. Doing so assures proper seal on installation and will make it easier to remove the filter when it is time to be replaced.

Remove the Current Filter:

6. Turn it a quarter turn (counter-clockwise) and pull it out of the housing.

Install the New Filter:

7. Insert it into the housing, O-rings cap end first. Push it all the way down until the O-rings end is firmly seated at the bottom.
8. Lock the filter into place by turning it one-quarter turn (clockwise).
9. Put housing lid back on and secure.
10. Open the inlet valve and relieve pressure on housing.

Distributed By:
neoLogic
solutions
filtration division

2299 Ridge Road Greenville, SC 29607
Tel: 888.859.1188 • Fax: 864.284.1819
Neologicsolutions.com • Info@Neologicsolutions.com