

INSTRUCTION SHEET

155531-43-S



155531-43-S KIT CONSISTS OF

1. 1 EP-10 CARTRIDGE
2. 6 SILIPHOS SPHERES
3. 1 NET GUARD SLEEVE

1 Step - 1

Stack 6 siliphos spheres into the net guard sleeve so that the spheres make a row

2 Step - 2

EP-10 cartridge into housing

3 Step - 3

Net guard sleeve with siliphos spheres into EP-10 cartridge.

4 Step - 4

Screw the housing back on the cap hand tight. Slowly turn the water back on and check for leaks.

