

Alpine Eliminator Installation Instructions

For POU Cooler



1. Remove cooler from packaging.
2. Turn bottled water connection adapter counter clockwise until it stops.



3. Using both hands, lift the bottled water connection adapter out of the cooler. Expect some resistance due to suction.
4. Place plastic ring on top of reservoir inside cooler.



4. Press plastic ring into the top of the reservoir.



5. Place POU lid on top of reservoir with dual floats down in reservoir.



6. Turn POU lid clockwise till it stops.



7. Remove locking clip from unattached line of tubing feeding the POU lid.



8. To detach tubing, pull collet ring in towards fitting with left hand and pull tubing out of fitting with right hand.



9. Once tubing has been removed from fitting, run it through the hole in the back of the cooler cover.



10. Push tubing back into quick connect fitting as far as it will go. Replace locking clip and place cooler cover on top of cooler.



11. Once cooler cover is positioned with Feel Well logo to the left of the cooler faucets, turn cover counter clockwise until it stops.