Water Filter Installation Instructions

Follow these simple instructions for your filter type.





Refrigerator Water Filter

Part 4396701RC

- 1. Locate the filter beneath the refrigerator door in the front base grill.
- 2. Rotate the cap counter clock wise ¼ turn. Note: there may be some water in the filter and some spilling may occur.
- 3. Pull the filter cartridge out.
- 4. Remove the cartridge grill cap by sliding it off the end of the used filter.
- 5. Remove the red shipping cap from the new filter.
- 6. Slide the grill cap onto the new filter end.
- 7. With new cartridge cap in the vertical position, insert the new filter cartridge into the base grill.
- 8. Rotation the cap clockwise 1/4 turn to a horizontal position
- Reduce water spurts by flushing air from the system. Run water continuously for 4 gallons (approximately 5 minutes) through the dispenser until water runs steady. Additional flushing may be required in some households where water is of poor quality.