


Parts Breakdown – UVSS-M Models (Monitored)



Parts Breakdown - UVSS-M Models			
Drawing#	Item#	Item Description	UV Models
1	82500	Lamp	UVSS-6M
	82501		UVSS-10M
	82502		UVSS-15M
2	82510	Quartz Sleeve	UVSS-6M
	82511		UVSS-10M
	82512		UVSS-15M
3	82510	Module Control	All UVSS-M Models
4	82001	Cord Power N/A Plug 120V	NA UVSS Models
	20011	Cord Power Euro Plug 230V	EU/PC UVSS Models
5	440245	Clamp Kit 2.5"	UVSS-6M UVSS-10M
	440140	Clamp Kit 3.5"	UVSS-15M
6	82072	Connector 4 pin	All UVSS-M Models
7	440228	Gland Nut Assembly	All UVSS-M Models
8	40000	Chamber, Stainless Steel	UVSS-6M
	430204		UVSS-10M
	430200		UVSS-15M
9	410888	R4 O-ring	All UVSS-M Models
10	82527	Spring	All UVSS-M Models
11	82520	UV Sensor Assy	UVSS-6M UVSS-10M
	82521	UV Sensor Assy	UVSS-15M
	82525	Solenoid Valve (optional): 3/4", 120V	UVSS-6M UVSS-10M
	82526	Solenoid Valve (optional): 1", 120V	UVSS-15M
	82528	Solenoid Valve (optional): 3/4", 230V	UVSS-6M UVSS-10M
	82529	Solenoid Valve (optional): 1", 230V	UVSS-15M
-	51575	Manual	All UVSS-M Models