PurTest® Lead Test

The PurTest® Lead Test can detect lead at very low levels, even below the EPA action level of 15 parts per billion (ppb).

Before you begin.....

- Keep tests out of the reach of children and pets. Do not ingest anything from this test kit. Do not drink water sample used for testing. Store and use at room temperature (60-86 F).
- Do not open packets or vial until you are ready to perform the tests.
 Do not use on hot water or water containing bleach
- detergents.

 4. Do not re-use any part of the test kit

 5. Read and follow all instructions carefully.

Instructions:


- Open foil packet and take out all contents. The test contains (1) Pesticide test strip, (1) sample vial and (1) dropper pipette, as well as a desiccant packet (to be discarded).
- 2. Using dropper pipette, place water sample in the test vial. To pick up sample, tightly squeeze the bulb at the end of the pipette and place the open end into water sample. Release the bulb to pick up sample. Use only (1) pipette full of water. Swirl vial gently for several seconds. Place vial on a flat
- surface.
 3. Place the test strip into test vial, with arrows pointing down.
- Wait (10) minutes. Do not disturb strip or vial during this time. Blue lines will appear on the strip.
- 5. Take the strip out of vial and read results:

Negative: The LEFT line (next to number 1) is darker than the RIGHT line (next to number 2).



If you only see the LEFT line (next to number 1), the test is negative.

POSITIVE: The RIGHT line (next to number 2) is darker than the LEFT line (next to number 1), or lines are equally dark (Both LEFT and RIGHT lines are equally dark).



6. Note: If no lines appear or both lines are very light, the test did not run properly and the result is not valid. If a test strip shows a positive result, your water sample may contain pesticides at a toxic level.

Note: If your water test outside the desired values, call the Safe Drinking Water Hotline at 800-438-1942 or call PurTest at 800-788-4825 for free advice.

Please note that PurTest® is a screening test and cannot be used to certify water as safe or unsafe for drinking. PurTest® provides approximate results ONLY when used in strict accordance with instructions. American Water Service LLC expressly disclaims any liability resulting from the use of this product. failure to follow instructions or reliance of test results.