



TAC Replacement cartridge is packed with media protected in a zip lock bag. Follow these simple steps to prepare the cartridge for use:

1. Remove contents of the media housing that will include 2 foam pads, gasket for use on the top of the cap and the TAC media
2. Place one foam pad into the housing. Push it to the bottom. (If housing only has one pad, use it on top of the media)
3. Pour the TAC media into the housing.
4. Place the other foam pad into the top of the housing
5. Replace the cap
6. Insert the entire housing assembly cap side up into the filter housing place the gasket on the top.
7. Re assemble the filter housing and