



Throw away the media, not the whole filter!



# In-line EZ-Clip Filters

# OASIS™

### Faucet water in. Filtered water out.

The EZ-Clip system is as easy to install as it sounds. Flexible tubing connects into the top and bottom of the filter with simple push-into-place, quick connect fittings, eliminating the need for labor-intensive fittings. The filter housing is secured to the wall by simply pushing it into the EZ-Clip bracket. Ideal where simplicity and space is a priority, the InLine EZ-Clip system reliably delivers tasty, clean water for appliances such as: coffee machines, refrigerators, drinking fountains, POU water coolers, and under-sink filtration systems.



#### Select the filter media of your choice

- CARBON**  
Chlorine, bad taste and odor (CTO)
- CARBON / PHOSPHATE**  
CTO + scale  
\*(improves life and performance of your appliance)
- CARBON / LEAD**  
CTO + lead
- CARBON / LEAD / PHOSPHATE**  
CTO + lead + scale  
\*(improves life and performance of your appliance)
- CERAMIC (INCL PUSHFIT MOUNT)**  
Bacteria + cysts (99.99%)
- SPUN-BONDED POLYPROPYLENE**  
Sediments

### EASY TO INSTALL

installs in minutes

### EASY TO MAINTAIN

filter media only needs to be changed every 6 months (under average usage)

### BENEFITS YOUR WATER APPLIANCES

can improve the life and performance of your water appliances by minimizing sediment, or scale build up in water pipes & valves

### HEALTHY

filters out harmful impurities in the water

### CUSTOMIZABLE

a variety of filter elements are available to handle a number of filtration tasks

### DELICIOUS

removes odor and undesirable tastes in the water caused by chlorine and other impurities

### ECO-FRIENDLY

unlike other filtration products, the InLine EZ-clip filter housing is reusable, and discarded filters are biodegradable or recyclable

### ECONOMICAL

lower in cost, to purchase and maintain, compared to other filtration and bottled water products

### How to Install the INLINE EZ-CLIP

- 1 - Screw in the EZ-Clip mount
- 2 - Place filter media into outer housing and close the cap tightly
- 3 - Push the tubes into the water outlet quick-connector (the cap side is the inlet)
- 4 - Click the filter body into the EZ Clip mount.